

Rostra RearSight 250-8004 Installation Instructions



ITEM	QTY	P/N	DESCRIPTION
1	1	2508201	3.5" FLIP DOWN LCD MONITOR
2	1	2508104	MINI CAMERA
3	1	2508507	SACK PART
A	10		CABLE TIES
B	1		SEALING PUTTY
C	4		IDC IN-LINE CONNECTOR
D	1		3M VHB TAPE, 3x3
E	1		SELF-TAPPING SCREW
F	1		WARRANTY TAG
4	1	FORM# 4927	INSTALLATION INSTRUCTIONS

Important Camera Installation Information:

- 1) Locate an area to mount camera at the rear of the vehicle. Ensure the location is accessible from the inside of the vehicle as to provide access to power supply cable. Be sure to allow connection to be accessible in the event product needs to be serviced.
- 2) Using provided hardware mount camera in a manner such that the area being viewed includes a minor portion of the rear of the vehicle. This will provide depth perception for viewing as the vehicle is driven in reverse.
- 3) Locate Reverse Light Circuit. Splice Reverse Wire to **Red** Lead of Camera. Locate a vehicle ground. Slice ground to **Black** Lead of Camera. Route remaining Power & Ground and RCA Harnesses to LCD Monitor. Plug RCA connector into mating reverse RCA (**Yellow**) on monitor.
- 4) When routing wires use care not to impede any safety functions of the vehicle. (*IE Air bag deployment area, steering wheel linkage...etc*). Use appropriate wire ties to keep wires in place after assembly.

Important 3.5" LCD Installation Information:

- 5) When mounting the LCD be sure to avoid placing the monitor in the path that impedes driver's ability to drive vehicle safely.
- 6) Power for the monitor comes from the reverse circuit of the vehicle (*Reference 2 above*). The LCD in this kit is intended for Reverse use only. Any installation method other than that called out in this Instruction Manual is not warranted by Rostra Precision Controls, Inc.
- 7) It is intended for the 3M tape and the self-tapping screw to be utilized in mounting the LCD.
- 8) Set the 3 switches on the side of the monitor to: Picture - REV, Video - 1 & Power - ON.



System Operation:

- 1) When the vehicle is placed into reverse gear the LCD monitor will come on showing the driver the area on which the camera is focused. This does not alleviate the driver of being responsible for objects not in the view of the LCD.