







Quick Reference Card 7 Day Digital Timer 1531



Webasto
Feel the drive







Setting the Time and Day of the Week:

- 1** Press  and hold for 2 seconds.
Time of day will start flashing.
- 2** Press  Or  To adjust time setting.
Once time is set, release button.
Flashing will stop after 5 seconds and day of the week will begin flashing.
- 3** Press  Or  To select day of the week.
Once set, wait for flashing to stop.

Operating Heater in Manual Mode:

- 1** Press  To turn the heater on.
The operation Indicator will light up.
- 2** Press  To turn the heater off.
The operation Indicator light will go out.

Programming Heater Starting Time:

- 1** Press **P** To begin timer programming.
 The timer memory location number starts flashing. Continue to press button until the desired memory location 1, 2 or 3 is visible.
- 2** Press  Or  To adjust start time setting.
 Once start time is set, release button. Flashing will stop after 5 seconds and day of the week will begin flashing.
- 3** Press  Or  To select day of the week.
 Heater will start on the time and day selected. Once set, wait for flashing to stop. To program the other 2 memory locations, repeat the above 3 steps for each memory location.

Recalling or cancelling a programmed start time:

- 1** Press **P** To cycle through memory locations.
 Any one of the 3 memory locations can be activated each time the button is pressed. After selecting the memory location you desire, you will be able to change the day and time setting if desired by repeating steps 1,2 and 3 above.
- 2** Press **P** repeatedly until no memory location number is visible on timer display.

Webasto Product N.A., Inc.
 15083 North Road
 Fenton, MI 48430
 Technical Assistance: 1-800-555-4518 (USA)
 1-800-667-8900 (CAN)
www.techwebasto.com