



Spare Parts Listing

Part Number	Description	Part Number	Description
103741	Fuse Flat 7.5A Brown	901228	Cap Protective Exhaust
103922	Fuse Flat 20A Yellow	901240	Connector Exhaust Formed Tube 2 Pc. 180°
14878A	Fuse Block	901244	Mounting Bracket Interior Thermostat
21446A	Flexible Combustion Air Hose	901398	Relay 12V
85014A	Fuel Pump Harness	903200	Standpipe Fuel 3/16" OD
901018	Tank Coolant 3 Qt.	906012	Enclosure Assy
901034	Switch / LED 12V	901217	Door Gasket Foam Sealant
901068	Light LED Indicator Red 12V	906013	Heat Exchanger Assembly
901070	Light LED Indicator Green 12V	901036	Fan Axial Motor 700 CFM
901154	Thermostat Interior 40° F	901072	Heat Exchanger
901177	Thermostat Warning	901236	Connector Coolant Copper 90 Deg with Bleeder
901193	Cover Latch Support LID	905150	Formed Hose 90° Rubber
901222	Fan Motor Thermostat		